

REPLACING A PRECI-HORIX RIDER

PRECI-HORIX attachments are supplied with the **1802** yellow standard riders.

If the retention of the rider no longer meets the requirements, it can be replaced with the **1805** white rider with reduced retention or the **1806** red rider with increased retention.

1. Cut the riders with a scalpel in two and remove them from the prosthesis.
2. Position the rider with the desired retention on the supplied **1705** insertion tool and press it in position.
3. Check if the required retention is attained.