

REBASING/RELINING A PROSTHESIS WITH PRECI-HORIX

1. Take a reline impression with the riders in the prosthesis.
2. Remove the riders from the prosthesis and fill up the space of the bar and the riders with plaster and separating liquid.
3. Pour a stone model. Remove the impression material. The use of a reline jig or flask is recommended.
4. Reline in routine technique.
5. Remove the silicone after polymerization.
6. Finish the prosthesis and incorporate new riders.