

REPLACING A PRECI-VERTIX FEMALE

The **1801** and **1811** PRECI-VERTIX attachments are supplied with the **1802** yellow standard females.

If the friction of the female no longer meets the requirements, it can be replaced with the **1805** white female with reduced friction or the **1806** red female with increased friction.

1. Use a small sharp instrument to remove the female from the prosthesis.
2. Position the required female on the supplied **1804** insertion tool and press it into the prosthesis.
3. Check if the required friction is attained.