

REBASING/RELINING A PROSTHESIS WITH PRECI-VERTIX

1. Place impression material on the gingival of the prosthesis and take a reline impression.
2. Remove the females with a sharp metal instrument from the prosthesis.
3. Completely fill up the metal sleeves with silicone.
4. Pour a stone model.
5. Reline the prosthesis in the usual manner. Use a reline flask or jig.
6. Remove the silicone from the metal sleeves and seat the new females (see INFO 026).