

<b>FABRICATION OF A NEW PROSTHESIS WITH PRECI-VERTIX</b>
--

1. Take a full arch impression.
2. Seat the **1819** pattern analogue in the cavity. The round opening is used for retention in the stone.
3. Seat the replaceable **1802** female over the male. Block out the undercuts of the attachment slightly conical with wax.
4. Proceed as described in INFO 014 or INFO 015.