

**REBASING/RELINING A PROSTHESIS WITH PRECI-CLIP**

1. Take a reline impression with the riders in the prosthesis.
2. Fill up the area of the riders and the bar with silicone, and pour a stone model.
3. Reline as usual. Use a reline flask or jig.
4. Activate or deactivate the riders after finishing and polishing if necessary (see INFO 107).