

<b>REBASING/RELINING A PROSTHESIS WITH PRECI-BALL</b>
-------------------------------------------------------

1. Take a reline impression with the females in the prosthesis.
2. Seat the **1201 D** model analogue in the females in the prosthesis.
3. Pour a stone model.
4. Complete routine reline procedure using a reline jig or flask.
5. Activate or deactivate the female after finishing and polishing if necessary (see INFO 053).