

FABRICATION OF A NEW PROSTHESIS WITH PRECI-CLIX

CHAIRSIDE PROCEDURE

1. Block out the undercuts of the female with soft wax.
2. Take a full arch impression using a custom-made impression tray.

LABORATORY PROCEDURE

1. Place the **1201 D** model analogue or the **RE H 14 + 1206 C** assembly in the impression.
2. Pour a working model with incorporated model analogues.
3. Make a new secondary construction.