

REBASING/RELINING A PROSTHESIS WITH PRECI-VERTIX AT M

1. Apply impression material to the tissue side of the prosthesis and take reline impression.
2. Fill up the females with silicone.
3. Pour a stone model.
4. Reline in routine technique. Use a reline jig or flask.
5. Remove the silicone from the females.
6. Replace the **1822** friction part if necessary (see INFO 128).