

**FABRICATION OF A NEW PROSTHESIS WITH PRECI-VERTEX AT M**

1. Take a full arch impression.
2. Seat the **1819** pattern analogue in the impression in the area of the males and pour a stone model.
3. Seat the **1827** duplicating dummy over the male. Block out the undercuts of the duplicating dummy slightly conical with wax.
4. Duplicate and make a refractory model.
5. Proceed as described in INFO 126.