

**ACTIVATING OR DEACTIVATING A FEMALE  
IN A PROSTHESIS WITH PRECI-BALL**

**ACTIVATING/SQUEEZING THE FEMALE SEGMENTS**

Press the **1220** activating tool carefully and step by step over the female, until the desired increased retention is attained.

**DEACTIVATING/SPREADING THE FEMALE SEGMENTS**

Press the **1221** deactivating tool carefully and step by step over the female, until the desired decreased retention is attained.